

Специальные клапаны AV, BRV, IPVA, QSB, VIV, прочие клапаны

Виды товаров: клапаны впуска воздуха, резервные клапаны грубой очистки, воздушные клапаны, клапаны утечки, поворотные клапаны-бабочки с четвертьоборотом, вакуумные изоляционные клапаны и др.

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ewc@nt-rt.ru || сайт: <https://edwards.nt-rt.ru/>



Inline Air Admittance Valve - IPVA10EK - 24V DC (normally closed), C41770200
C41770200



Inline Air Admittance Valve - IPVA10EK - 24V DC (normally open), C41760200
C41760200



Leak Valve - LV10K - NW10 Flanges, C37102000
C37102000



VIV Valve - VIV25EKA - 100-115V AC, A50637501
A50637501



VIV Valve - VIV25EKA - 208V-230V AC, A50637502
A50637502



VIV Valve - VIV25EKA - 24V DC, A50637500
A50637500



VIV Valve - VIV40EKA - 208V-230V AC, A50637512
A50637512



VIV Valve - VIV40EKA - 24V DC, A50637510
A50637510



VIV Valve - VIV50EKA - 24V DC, A50637520

A50637520



VIV Valve Electronics - VIV LINK C13/C14 100-240V, A50637580

A50637580



VIV Valve Electronics - VIV LINK C19/C20 100-230V 50/60 Hz, A50637590

A50637590



VIV Valve Kit - VIV40EKA 24V DC + VIV LINK C19/C20 100-230V AC + FITTINGS KIT, KIT001457

KIT001457

VIV Valve - VIV40EKA - 100-115V AC, A50637511

A50637511



Air Admittance Valve - AV10K, C35103000

C35103000



Air Admittance Valve - AV5A - with couplings, C35003000

C35003000



Backing/Roughing Valve - BRV10K - Manual AI NW10, C32103000

C32103000



Backing/Roughing Valve - BRV10PK - Pneumatic NW10, C32104000

C32104000




Backing/Roughing Valve - BRV25K - Manual AI NW25, C32303000

C32303000



Backing/Roughing Valve - BRV25PK - Pneumatic AI NW25, C32304000

C32304000



Backing/Roughing Valve - BRV25PK - Pneumatic AI NW25, C32303500

C32303500




Butterfly Valve - QSB100 - Quarter Swing Valve Manual, B42602000

B42602000



Butterfly Valve - QSB100P - Quarter Swing Valve Pneumatic, B42603000

B42603000



Butterfly Valve - QSB100P - Valve Pneumatic Reed Switch, B42609000

B42609000



Butterfly Valve - QSB160 - Quarter Swing Valve Manual, B42802000

B42802000




Butterfly Valve - QSB160P - Quarter Swing Valve Pneumatic, B42803000

B42803000

Butterfly Valve - QSB250P - Quarter Swing Valve Pneumatic, B43003000

B43003000



Butterfly Valve - QSB63 - Quarter Swing Valve Manual, B42402000

B42402000



Butterfly Valve - QSB63P - Quarter Swing Valve Pneumatic, B42403000

B42403000



Butterfly Valve - QSB63P - Valve Pneumatic Reed Switch, B42409000

B42409000



Inline Air Admittance Valve - IPVA10EK - 110V AC (normally closed), C41770100

C41770100



Inline Air Admittance Valve - IPVA10EK - 110V AC (normally open), C41760100
C41760100



Inline Air Admittance Valve - IPVA10EK - 230V AC (normally closed), C41770000
C41770000




Inline Air Admittance Valve - IPVA10EK - 230V AC (normally open), C41760000
C41760000



VALVE ENCL INFILL FM PK1, M52000744

M52000744



Valve Piston PK1, 602-181-703

602-181-703



VALVE BOX E2M275, A36701048

A36701048



Valve Button E2M-2/5/8 BO, A26501017

A26501017



VALVE CAP 148 212 412, 607-354-002

607-354-002



Valve Cap, 403-626-003

403-626-003



Valve Chk Crtg Brs Body 1"D X, 085-050-122

085-050-122




VALVE DISC, 429-925-001

429-925-001



VALVE DISC, 429-937-002

429-937-002



Valve Piston, 602-181-003

602-181-003




VALVE PNEUMATIC SPARE CXS, D37488794

D37488794



VALVE POPPET 148 212 412, 607-415-001

607-415-001



VALVE RETAINER-PAINTED GV/CHEM PK1, A70501749

A70501749



VALVE SEAT 148 212 412, 607-353-003

607-353-003

Valve Seat Assy PRV DP Swing Type, A70501143

A70501143



Valve Seat DP250, A70501064

A70501064



Valve Seat, 403-636-002

403-636-002



VALVES, 1625054358

1625054358




CXS FM VALVE TERM BOX ASSY PK1, M52000710

M52000710



REMOVABLE VALVE ENCL FM PK1, M52000723

M52000723




RV Reed Valve Baffle PK10, A21035730

A21035730




VALVE DECK SUB-ASSY, 423-490-001

423-490-001



NON-RETURN VALVE, 1637000457

1637000457



Oil Pressure Valve RV, A25908129

A25908129




PCA VALVE TERM IF FM SPARE CXS, D37488733

D37488733




PNEUMATIC VALVE 1/8BSPP PORTS PK1, A60032012

A60032012



RV DUMP VALVE, A25908226

A25908226



RV Reed Valve Baffle, A21035130

A21035130



RV Reed Valve, A65201029

A65201029



Stem Valve, 606-002-001

606-002-001




THERMO. OPERATED WATER VALVE AVTA 15, E6529208
E6529208



VALVE 87 DEGREE CELCIUS, 1622706407
1622706407




VALVE ACTUATOR, 1639000134
1639000134



Valve Body IPV40KA, C41641802
C41641802

Valve Body IPV40KS, C41642811

C41642811



VALVE BODY PK 1, A34601738

A34601738



Valve Body PV10Ka, C41101816

C41101816




Valve Body PV25Ka, C41301816

C41301816



Valve Body Pv25Ks, C41622801

C41622801



Valve Body PV40Ka, C41401816

C41401816



Valve Body PV40KS, C41642801

C41642801



VALVE BOX E2M175, A36601047

A36601047



AIRING VALVE 610_2400, 80300000N9A
80300000N9A



AIRING VALVE LRP50-80 SERIES, 80500000N9A
80500000N9A



Butterfly Valve Tyco 3", A60032613
A60032613



CDX Vent Valve Flame ARRSTR SP, A70801710
A70801710



Clapper Valve Zytel, 276-781-002

276-781-002



COVER THERMOSTAT VALVE V146, 1637000249

1637000249




Distributor Valve E2M18, A34301034

A34301034



Distributor Valve, A26501035

A26501035



Drain Valve (339-30), 085-036-339

085-036-339



Flush Vent Valve EXT255 Pk10, B74001101

B74001101



GREASE VALVE HOUSING 3280_21850, 41600000N9A

41600000N9A



GREASE VALVE HOUSING 4510_22500, 41700000N9A

41700000N9A

HOUSING VACUUM CONTROL VALVE, 1625390264

1625390264



Inlet Valve Assembly, A44001000

A44001000




Inlet Valve Guide, 1637000204

1637000204




INLET VALVE SHUTTER (PK1), E08741716

E08741716



INSERT, VALVE CAP 148 212 412, 607-416-001

607-416-001



Mains Socket For PVE Valve, E21909695

E21909695



MOUNTING SHEET METAL THERMO. VALVE CHEM, E6530053

E6530053



NDLE VLV 1/4-1/4 SS PK1, H03537734

H03537734



По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижегород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ewc@nt-rt.ru || сайт: <https://edwards.nt-rt.ru/>